

Sunpro Brand by Arizona RV Parts, Inc.

Instructions for Windshield Patterns

Tools Needed:

Ladder

Tape – Use a tape that does not leave a residue or damage the surface, we recommend masking tape.

Black Marker

Before making your pattern try to visualize how it will fit and make it accordingly.

1) Stretch the plastic across your windshield and tape in place with as few wrinkles as possible. Do not use Paper

Front Windshield:

2) Trace the outside of the frame or gasket of the windshield which ever is the most outer. You must trace around anything that is within 3 inches of the frame or gasket. Wiper motors and mirrors quite often are in the 3-inch zone.

Driver Door:

3) Place plastic over entire door and trace the whole doorframe. Then trace around the window(s). This way we will know how much space we have for fasteners.

Passenger Door or Window:

4) Follow same instructions as driver door.

Windshield Wipers:

You will need to measure the length of your wiper.

If You Can:

If you can take a picture of the front and sides it always helps. The pictures can be e-mailed to 909@2154157.com or Texted to 406-961-8688. This is not mandatory, only a suggestion.

Please Note: The pattern is only as good as you make it! We do not guarantee your work. Please take your time and make any needed notes understandable.

Existing Fasteners:

If you have existing fasteners and *Do Not* have the old windshield and side window covers mark the fastener on the plastic with a dot and then put a small arrow next to it so we can easily identify it.

If you *Do Have* the old covers please send them back so we can use them as the patterns. If you have existing fastener's we can't guarantee that the fit will be as good as a new installation. We prefer not to install the fasteners, it is very hard to do correctly without the RV. If you ask us to do it, we will do our best to match them as close as possible, we do not guarantee the fit.

Where to send your pattern By US Mail:

After you have completed all of the steps needed to make your pattern, please send it to the following address.

Arizona RV Parts, Inc.

Attention: Sewing Dept.

PO Box 2193

Hamilton, MT 59840

Please include your name and a phone number where you can be reached during the day.

Installation instructions will come with your windshield cover and they are also available on our website for you to review in advance. Twist Lock and snap installation will require a drill bit and Dual Lock will require Rubbing Alcohol to clean the surface prior to installing the Dual Lock.

Twist Locks with screws require a 7/64" Drill Bit

Snaps with screws Require a 1/8" Drill Bit

www.sunpromfg.com

For a complete line of sun protection products or anything you might need for your RV visit our website or call us toll free @ **800-789-5588**.